



**Institute of
Applied Physics**

Friedrich-Schiller-Universität Jena

Lens Design I

Lecture 5: Advanced handling

2024-05-16

Ziyao Tang



Preliminary Schedule - Lens Design I 2024



1	04.04.	Basics	Zhang	Introduction, Zemax interface, menus, file handling, preferences, Editors, updates, windows, coordinates, System description, 3D geometry, aperture, field, wavelength
2	18.04.	Properties of optical systems I	Tang	Diameters, stop and pupil, vignetting, layouts, materials, glass catalogs, raytrace, ray fans and sampling, footprints
3	25.04.	Properties of optical systems II	Tang	Types of surfaces, cardinal elements, lens properties, Imaging, magnification, paraxial approximation and modelling, telecentricity, infinity object distance and afocal image, local/global coordinates
4	02.05.	Properties of optical systems III	Tang	Component reversal, system insertion, scaling of systems, aspheres, gratings and diffractive surfaces, gradient media, solves
5	16.05.	Advanced handling I	Tang	Miscellaneous, fold mirror, universal plot, slider, multiconfiguration, lens catalogs
6	23.05.	Aberrations I	Zhang	Representation of geometrical aberrations, spot diagram, transverse aberration diagrams, aberration expansions, primary aberrations
7	30.05.	Aberrations II	Zhang	Wave aberrations, Zernike polynomials, measurement of quality
8	06.06.	Aberrations III	Tang	Point spread function, optical transfer function
9	13.06.	Optimization I	Tang	Principles of nonlinear optimization, optimization in optical design, general process, optimization in Zemax
10	20.06.	Optimization II	Zhang	Initial systems, special issues, sensitivity of variables in optical systems, global optimization methods
11	27.06.	Correction I	Zhang	Symmetry principle, lens bending, correcting spherical aberration, coma, astigmatism, field curvature, chromatical correction
12	04.07.	Correction II	Zhang	Field lenses, stop position influence, retrofocus and telephoto setup, aspheres and higher orders, freeform systems, miscellaneous




1. Miscellaneous
2. Universal plots
3. Multi-configuration

- Object in infinity
 - **On-axis Field:** incoming marginal ray parallel to axis
 - first distance infinity
 - off-axis field only as angle
 - no initial NA possible
- Image in infinity
 - **On-axis Field:** outgoing marginal ray ideally parallel to axis
 - explicit declaration: 'afocal image space'
 - geometrical aberrations as angles
 - wave aberration reference is plane wave
 - definition of Airy diameter in mrad
- Entrance pupil in infinity
 - **All Field:** incoming chief ray parallel to axis
 - explicit declaration: 'telecentric object space'
- Exit pupil in infinity
 - **All Field:** outgoing chief ray ideally parallel to axis


- In the menu OPTIMIZE– QUICK FOCUS we have the opportunity to adjust the image location according to the criteria
 1. Spot diameter
 2. Wavefront rms
 3. Angle radius
- In principle, this option is a simplified optimization
- Example: find the best image plane of a single lens
-











Spot before and after performing
the optimal focussing




- In the menu OPTIMIZE – QUICK ADJUST we have the opportunity to adjust
 1. one thickness
 2. one radiussimilar to the quick focus function, but not limited for image distance.
But: the effect is iterative, in case of nonlinearities, some calls are necessary
- As criteria, wavefront, spot diameter or angular radius is possible
- Example: Move a lens in between a system to focus the image



Spots before and after the adjustment



- Slider option in menu: Optimize - Slider
- Observation of the system depending on a varying parameter
- Automatic scan or manual adjustment possible



The screenshot shows a software window titled "Slider". It contains a table with columns: Type, Parameter, Surface, Window, Start, Stop, $\pm \Delta$, and Value. The first row is selected and shows a checked checkbox, the number 1, "Surface", "Thickness", "11", "All", "54.106", "55.199", a range with plus and minus signs, a slider bar, and the value "54.652". Below the table is a checkbox labeled "Update ZPL Windows". At the bottom right are three buttons: "Animate", "Keep and Exit", and "Exit", followed by a help icon.



	Type	Parameter	Surface	Window	Start	Stop	$\pm \Delta$		Value
<input checked="" type="checkbox"/>	1	Surface	Thickness	11	All	54.106	55.199	+ -	54.652

☐ Update ZPL Windows

Animate Keep and Exit Exit ?

Lens Catalogs

- Lens catalogs:
Data of commercial lens vendors
- Searching machine for one vendor
- Components can be loaded or inserted
- Preview and data prescription possible
- Special code of components in brackets according to search criteria



0: Catalog Report

Listing of data for vendor: LINOS PHOTONICS

Search criterion:
Effective Focal Length not restricted
Entrance Pupil Diameter not restricted
Possible Shapes: Equi-, Bi-, Plano-, Meniscus
Possible Types: Spherical, GRIN, Aspheric, Toroidal
Number of Elements: Any #

Number of files meeting search criterion: 399 (of 399 total)



Sorted by Part Name

Part Name	EFL	EPD	Shape	Type	# Elements
033481000	19.98	5.00	?	S	2
033484000	60.03	14.00	?	S	2
033486000	119.60	22.00	?	S	2
033490000	199.40	45.00	?	S	2
033493000	309.60	73.00	?	S	2
033497000	-19.19	6.00	?	S	2
033499000	-38.30	10.00	?	S	2
311026000	27.78	20.00	E	S	1
311027000	85.66	20.00	E	S	1
311192000	56.33	36.00	E	S	1
311193000	109.70	36.00	E	S	1
311194000	137.70	36.00	E	S	1
311195000	175.50	36.00	E	S	1
311196000	217.50	36.00	E	S	1
311200000	46.70	45.00	B	S	1
311203000	11.14	9.00	E	S	1
311204000	12.41	11.00	E	S	1


LINOS PHOTONICS

DAHENG OPTICS
DIAS INFRARED
DIVERSEOPTICS
EALING
EDMUND OPTICS
EKSMA OPTICS
ESCO
GELTECH
ISP OPTICS
LIGHT PATH
LIMO
LINOS PHOTONICS
NEWPORT CORP
NSG
OPTICS FOR RESEARCH
OPTOSIGMA
PHILIPS
QI OPTIQ POLYMER
ROSS OPTICAL
RPO
SIGMA KOKI
SPECIAL OPTICS
THORLABS



- Some system with more than one lens available
- Sometimes:
 - aspherical constants wrong
 - hidden data with diameters, wavelengths,...
 - problems with old glasses
- Data stored in binary .ZMF format
- Search over all catalogs not possible
- Catalogs changes dynamically with every release
- Private catalog can be generated



- Possibility to generate individual plots for special properties during changing one or two parameters
- The sensitivity of the correction can be estimated
- One-dimensional:
spot size by changes of an air thickness
- Universal plot configurations can be saved and called later
- Useful example: spot diameter as a function of a variable: operator RSCH



- Two-dimensional case:
change of one air gap, readjustment of image distance




Establish a generalized 4-f-optical system with the achromatic lens LAL 50.0 -20.0 from the catalog of CVI Melles and Griot with focal length $f_1 = 50$ mm as front lens and LAO 200.0 - 50.0 with $f_2 = 200$ mm as a rear group. The wavelength should be 632 nm and the initial numerical aperture $NA = 0.1$.

- a) What is the numerical aperture in the image space ?
- b) If the stop is located in the intermediate focal point, the system is both sided telecentric. If the object sided telecentricity is forced explicitly in Zemax, determine the residual telecentricity error in the image space as a function of the object field height between $y = 0$ and 4 mm as a universal plot.
- c) Generate a two-dimensional universal plot, which shows the spot rms-diameter in the image on axis as a function of the object distance and the image distance. The distances should be varied in a range of 10 mm in the object space and 20 mm in the image space.
- d) If the lens groups are turned around, the performance of the image is worse. Compare the two spot diameters of both configurations. What happens to the telecentricity criterion of b) ?


- Multi configuration editor
- Establishment of different system paths or configurations
- Examples:
 1. Zoom systems, lenses moved
 2. Scan systems, mirror rotated
 3. Switchable optics, components considered / not taken into account
 4. Interferometer, test and reference arm
 5. Camera with different object distances
 6. Microscope tube system for several objective lenses
 7. ...
- In the multi configuration editor, the parameters / differences must be defined
- Many output options and the optimization can take all configurations into account
- Special option: show all configuration in the 3D layout drawing simultaneously
 1. shifted, for comparison
 2. with same reference, overlaid

- Multi configuration editor: Setup menu



- Change of configuration

Shortcut: Ctrl+A



The image shows a screenshot of the "Lens Data" window. The "Surface 1 Properties" tab is selected, and the "Configuration 2/5" indicator is circled in red. The table below shows the properties of the surfaces.

	Surf:Type	mum Term #	Norm Radius	Coeff. on p ¹	Coeff. on p ²	Coeff. on p ³	Coeff. on p ⁴
0	OBJECT Standard ▾						
1	STOP Extended Odd Asphere ▾	100	100.000	0.000	0.000	0.000	0.000

Exercise 2: Twyman-Green-Interferometer



A Twyman-Green interferometer is classically used in the optical shop for measuring optical surfaces. The setup corresponds to a Michelson interferometer and can easily be established as a multiconfiguration.

a) Establish first the test arm of the interferometer above. The beam splitter is made of BK 7 with a length of 20 mm. The auxiliary lens is biconvex with radii of 100 mm made of SF6 with a thickness of 5 mm, the test surface is convex with a radius of 35.88843 mm. The objective lens is made of SF6 with thickness 12 mm and the radii 95.1413 mm and -858.5581 mm. The wavelength is 632.8 nm and the incoming beam diameter 16 mm.

b) Now insert the test arm with the corresponding data before the objective lens. Define a multiconfiguration and mark the corresponding not used surfaces by IGNR (ignore).

c) Establish an interferogram. See the change of the fringes, if the test surface is moved along the axis.

