


Group 1 – 18.04.2024



Seminars tutor: Joao Pedro Berti Ligabo  
Lecturers: Dr. Yueqian Zhang  
Dr. Ziyao Tang

# Lens Design I (SS' 24)

## Seminar 1

# Exercise 1-1: “Stair-mirror-setup” (Homework)

A system with a stair mirror pair, which decenters an incoming collimated ray bundle.

- Beam diameter = 10 mm;
- Beam decentration = 40 mm in the -Y direction;
- Beam wavelength ( $\lambda$ ) = 632.8 nm.

After this pair of mirrors, a decentered main objective lens with focal length  $f = 200 \text{ mm}$  made of **BK7** is located **25 mm below the optical axis** and focusses the beam.

## Questions / Tasks:

- a. Setup the system.
- b. Generate layout drawings in 3D as well as “Shaded Model”.
- c. Check the beam cross section on the second mirror, what is the size of the pattern?
- d. Determine the optimal sensor plane location. Check the spot of the focused beam. Discuss the shape of this pattern.

# Exercise 1-2: “Symmetrical 4F-system”

A telecentric 4F imaging system with two identical plano-convex lenses:

- Lenses' material = BK7;
- Lenses' thickness (d) = 10 mm;
- Approximate lenses' focal length (f) = 100 mm;
- Object space NA = 0.2;
- Object diameter = 10 mm;
- Beam wavelength ( $\lambda$ ) = 546.1 nm.

## Questions / Tasks:

- a. First, for perfectly symmetrical setup, determine the layout and the spot diagram of the system.
- b. Optimize the image location. Why is the spot size improved?
- c. If the starting aperture is decreased, the system becomes more and more close to diffraction limited. What is the value of the NA to get a diffraction limited system on axis? Take in mind here, that a re-focusing might be necessary due to the lowered spherical aberrations, which depends on the aperture.

# Exercise 1-3: “Apertures, stops and vignetting”

Load the achromat **AAP-125.0-25.4** from the lens catalogue (**CVI Melles Griot,  $f = 125\text{mm}$** ). Set the diameter of the **entrance pupil to 20 mm** and the **wavelength to 546.1 nm**. Display the wavefront of the achromat for the **field points  $0^\circ$ ,  $3^\circ$  and  $5^\circ$**  with different stops and apertures:

- With the stop surface at 1<sup>st</sup> surface of the system;
- With the stop surface at the front focal plane (for finding the position of the focal plane, use Analysis → Rays and Spots → Cardinal Points);
- With adjusted entrance pupils using System Data → Fields → Settings → Set Vignetting;
- Insert a circular central obscuration with 6 mm radius at the 1<sup>st</sup> surface of the achromat and recalculate the wavefront with and without vignetting factors;
- Clear all vignetting, then calculate the ray intersection coordinates (REAY) at the last surface for the upper marginal ray and the chief ray of field  $5^\circ$  in the merit function editor. Interpret the result.



# Thank you for attention!

End of Seminar 1