

Metrology and Sensing

Lecture 13-2: Confocal sensors

2020-02-09

Herbert Gross

Content




- Resolution
- Pinhole size
- Impact of aberrations
- Chromatical confocal method



Lateral and Axial Resolution



- Tradeoff between:
 - 1. lateral resolution
 - 2. axial resolution
 - 3. signal to noise ratio (detection yield)



Ref: U. Kubitschek

Confocal Microscopy: PSF and Lateral Resolution



Normalized transverse coordinate v

$$v = \frac{2\pi}{\lambda} \cdot x' \cdot \sin \alpha$$


Usual PSF: Airy

$$I(v) = \left\lceil \frac{2J_1(v)}{v} \right\rceil^2$$

Confocal imaging:
 Identical PSF for illumination and observation assumed

$$I(v) = \left[\frac{2J_1(v)}{v}\right]^4$$

Resolution improvement be factor 1.4 for FWhM



Confocal Microscopy: Axial Sectioning



- Normalized axial coordinate
- Conventional wide field imaging:
 Intensity on axis

$$I(u) = \left[\frac{\sin(u/2)}{u/2}\right]^2$$

Axial resolution

$$\Delta z_{wide}^{(approx)} = \frac{0.45 \cdot \lambda}{n! \cdot (1 - \cos \theta)}$$


Confocal imaging: Intensity on axis

$$I(u) = \left\lceil \frac{\sin(u/2)}{u/2} \right\rceil^4$$

Axial resolution improved by factor 1.41 for FWhM


$$\Delta z_{confo} = \frac{0.319 \cdot \lambda}{n' \cdot (1 - \cos \theta)}$$

$$u = \frac{8\pi}{\lambda} \cdot z \cdot \sin^2(\alpha/2)$$



Confocal Signal for Different Pinhole Sizes

- Numerical result for different sizes a of the fiber radius
- The width increases with the fiber diameter
- The diffraction fine structure disappears with growing a







Size of Pinhole and Confocality

- Large pinhole: geometrical optic
- Small pinhole:
 - Diffraction dominates
 - Scaling by Airy diameter a = D/D_{Airy}
 - diffraction relevant for pinholes
 D < D_{airy}
- Confocal signal: Integral over pinhole size

$$S(u) = \int_{0}^{a} \left| U(u, v) \right|^{2} 2\pi v \, dv$$









Variable Pinhole Diaphragm




- Real shape of pinhole: quadratic or circular signal depends on shape
- Variable pinhole easy to realy quadratic
- Rreis Quadrat senkrecht 45° gekippt x
- Typical size:D_{pinhole} = 0.5...2 D_{airy}
- Easy to fabricate: approx. 30 mm
 very small numerical aperture in pinhole objective lens helps





Confocal Signal with Spherical Aberration

- Spherical aberration:
 - PSF broadened
 - PSF no longer symmetrical around image plane during defocus
- Confocal signal:
 - loss in contrast
 - decreased resolution







Institute of Applied Physics


Friedrich-Schiller-Universität Jena

Confocal Signal with Spherical Aberration

- Spherical aberration with Zernike coefficient W₄₀
- Integration over finite size pinhole with radius a
- Asymmetry and width depends on a and W₄₀
- Large pinhole:
 - depth discrimination decreased
 - fine structure disappears
- Sphärische Aberration mit Koeffizient W₄₀










Confocal Distance Sensor



Principle of the confocal distance sensor




Confocal Depth Measuring System

- Fourier optical model:
 - object/sample to be assumed as a plane mirror
 - fiber source incoherent, diameter D_{fib}, uniformly radiating
 - optical system with point spread function h_{psf}
 - confocal detection by fiber (pinhole) size D_{fib}
- Incoherent imaging model to get the intensity of at the fiber
- Calculation of the confocal signal by integration over the pinhole

$$I_{ima}(a, \Delta z) = I_{fib}(a) \otimes \left| h_{psf}(\Delta z) \right|^2$$

$$S_{conf}(a, \Delta z) = \iint_{r < a} I_{ima}(a, \Delta z) dx dy$$





Surface Smoothness

Institute of
Applied Physics
Friedrich-Schiller-Universität Jena


- Smooth / polished surface:
 - only reflected light is measured
 - maximum acceptable slope of the sampe surface

$$\alpha_{\text{max}} = arc \sin(NA)$$

NA	maximum angle α
0.3	18°
0.4	24°
0.5	30°
0.6	37°
0.7	44°




- larger slopes can be measured
- quantitatively the BRDF determines the limit



Ghost Foci



- If parts of a polished sample are spherical in shape:
 - ghost foci with high intensity
 - wrong interpretation of the depth out of the signal








Chromatical Confocal Sensor



- Spectral sensitive sensor
- Objective lens with large axial chromatical aberration











Confocal Imaging with Hyper Chromate



- Wide field 20x0.5
- Confocal with chromate at low aperture 20x0.5
- Confocal with chromate at high aperture 50x0.9










Principle



- Goal:
 - 1. large chromatical spreading (large CHL) Δz
 - 2. large numerical aperture
 - 3. corrected spherochromatism
- In the case of a large ratio Δz / f, the numerical aperture shows a considerable change in the measuring interval
- Design approach:
 - 1. Achromate with positive flint and negative crown
 - 2. Achromates cascaded
 - 3. Improved spherochromatism by asphere
 - 4. monochromatic lens with buried surface adapter





Optical Design



Case 1-1

$$\begin{aligned} NA_{image} &= 0.3, \, NA_{object} = 0.22 \\ \Delta z &= 3 \, mm, \, f = 13 \, mm \\ z_{free} &= 16.3 \, mm \end{aligned}$$

1st surface: aspherical

