



**Institute of
Applied Physics**

Friedrich-Schiller-Universität Jena

Lens Design I

Lecture 1: Basics

2024-04-04

Yueqian Zhang



Preliminary Schedule - Lens Design I 2024


1	04.04.	Basics	Zhang	Introduction, Zemax interface, menus, file handling, preferences, Editors, updates, windows, coordinates, System description, 3D geometry, aperture, field, wavelength
2	18.04.	Properties of optical systems I	Tang	Diameters, stop and pupil, vignetting, layouts, materials, glass catalogs, raytrace, ray fans and sampling, footprints
3	25.04.	Properties of optical systems II	Tang	Types of surfaces, cardinal elements, lens properties, Imaging, magnification, paraxial approximation and modelling, telecentricity, infinity object distance and afocal image, local/global coordinates
4	02.05.	Properties of optical systems III	Tang	Component reversal, system insertion, scaling of systems, aspheres, gratings and diffractive surfaces, gradient media, solves
5	16.05.	Advanced handling I	Tang	Miscellaneous, fold mirror, universal plot, slider, multiconfiguration, lens catalogs
6	23.05.	Aberrations I	Zhang	Representation of geometrical aberrations, spot diagram, transverse aberration diagrams, aberration expansions, primary aberrations
7	30.05.	Aberrations II	Zhang	Wave aberrations, Zernike polynomials, measurement of quality
8	06.06.	Aberrations III	Tang	Point spread function, optical transfer function
9	13.06.	Optimization I	Tang	Principles of nonlinear optimization, optimization in optical design, general process, optimization in Zemax
10	20.06.	Optimization II	Zhang	Initial systems, special issues, sensitivity of variables in optical systems, global optimization methods
11	27.06.	Correction I	Zhang	Symmetry principle, lens bending, correcting spherical aberration, coma, astigmatism, field curvature, chromatical correction
12	04.07.	Correction II	Zhang	Field lenses, stop position influence, retrofocus and telephoto setup, aspheres and higher orders, freeform systems, miscellaneous



1. Introduction
2. Zemax interface, menus, file handling, preferences
3. Editors, updates, windows
4. Coordinate systems and notations
5. Aperture, field, wavelength
6. System description
7. 3D geometry



What is Lens Design (Optical Design)






Modelling of Optical Systems

- Principal purpose of calculations:


1. Solving the direct problem of understanding the properties: analysis
2. Solving the inverse problem: Finding the concrete system data for a required functionality: synthesis





Model depth of Light Propagation


- Different levels of modelling in optical propagation
- Schematical illustration (not to scale)




- Five levels of modelling:

1. Geometrical raytrace with analysis
2. Equivalent geometrical quantities, classification
3. Physical model: complex pupil function
4. Primary physical quantities
5. Secondary physical quantities

- Blue arrows: conversion of quantities



Key Skills of Optical Designers



- There are 4 types of windows in Zemax:
 1. Editors for data input:
lens data, extra data, multiconfiguration, tolerances
 2. Output windows for graphical representation of results
Here mostly setting-windows are supported to optimize the layout
 3. Text windows for output in ASCII numerical numbers (can be exported)
 4. Dialog boxes for data input, error reports and more

- There are several files associated with Zemax
 1. Data files (.ZMX)
 2. Session files (.SES) for system settings (can be de-activated)
 3. Glass catalogs, lens catalogs, coating catalogs, BRDF catalogs, macros, images, POP data, refractive index files,...


- There are in general two working modes of Zemax
 1. Sequential raytrace (or partial non-sequential)
 2. Non-sequential

1. Kingslake **Lens design fundamentals, SPIE Press, 2010**
2. Mouroulis / McDonald Geometrical Optics and Optical Design, Oxford, 1997
3. Fischer / Tadic-Galeb Optical System Design, McGraw Hill, 2000
4. Malacara / Malacara Handbook of Lens Design, Dekker, 2013
5. Laikin **Lens Design, Dekker, 2007**
6. W. Smith Modern Optical Engineering, Graw Hill, 2000
7. W. Smith Modern lens design, McGraw Hill, 2005
8. Geary Lens Design with practical Examples, Willmann-Bell, 2002
9. Gross (Ed.) **Handbook of optical systems, Vol 1-5, Wiley, 2005-2012**
10. Shannon The art and science of optical design,
Cambridge Univ. Press, 1997
11. G. Smith Practical computer-aided lens design, Willman Bell, 1998
12. R. Kingslake/B. Johnson Lens Design Fundamentals, Academic Press, 2010
13. H. Sun Lens design a practical guide, CRC Press 2017
14. A. Yabe Optimization in Lens design, SPIE Press, 2018
15. Kidger **Fundamental Optical Design, SPIE Press, 2001**

- Necessary data for system calculation:
 1. system surfaces with parameters (radius)
 2. distances with parameters (length, material)
 3. stop surface
 4. wavelength(s)
 5. aperture
 6. field point(s)


- Optional inputs:
 1. finite diameters
 2. vignetting factors
 3. decenter and tilt
 4. coordinate reference
 5. weighting factors
 6. multi configurations
 7. ...

- Single step:
 - surface and transition
 - parameters: radius, diameter, thickness, refractive index, aspherical constants, conic parameter, decenter, tilt,...



- Complete system:
 - sequence of surfaces
 - object has index 0
 - image has index N
 - t_N does not exist


- Ray path has fixed sequence
0-1-2-...-(N-1)-N








Coordinate systems and sign of quantities

- Coordinate systems
2D sections: y-z shown




- Sign of lengths, radii, angles:



Definition of Aperture and Field

- Imaging on axis: circular / rotational symmetry
Only spherical aberration and chromatical aberrations
- Finite field size, object point off-axis:
 - chief ray as reference
 - skew ray bundles: coma and distortion
 - Vignetting, cone of ray bundle not circular symmetric
 - to distinguish: tangential and sagittal plane



Quantitative measures of relative opening / size of accepted light cone

- Numerical aperture


$$NA = n \cdot \sin u'$$

- F-number

$$F\# = \frac{f'}{D_{EX}}$$

- Approximation for small apertures:

$$F\# = \frac{1}{2 \cdot NA}$$



Important Test Wavelengths



λ in [nm]	Name	Color	Element
248.3		UV	Hg
280.4		UV	Hg
296.7278		UV	Hg
312.5663		UV	Hg
334.1478		UV	Hg
365.0146	i	UV	Hg
404.6561	h	violett	Hg
435.8343	g	blau	Hg
479.9914	F'	blau	Cd
486.1327	F	blau	H
546.0740	e	grün	Hg
587.5618	d	gelb	He
589.2938	D	gelb	Na
632.8			HeNe-Laser
643.8469	C'	rot	Cd
656.2725	C	rot	H
706.5188	r	rot	He
852.11	s	IR	Cä
1013.98	t	IR	Hg
1060.0			Nd:YAG-Laser

Zemax Toolbars



Zemax OpticStudio 14.2 Professional - 36156 - Microscopic lens 40x0.65 Kidger mod

File Setup Analyze Optimize Tolerance Libraries Part Designer Programming Help

Materials Catalog Materials Analyses Materials Tools Glass Substitution Template

Optical Materials

Lens Catalog Make Private Catalog Test Plate Lists

Stock Parts

Coating Catalog Coatings Tools

Coatings

IS Scatter Catalog ABg Scatter Catalog Scatter Function Viewer Scatter Polar Plot

Scattering

Radiant Source Models IES Source Models Spectral Source Models

Sources

Zemax OpticStudio 14.2 Professional - 36156 - Microscopic lens 40x0.65 Kidger modified.ZMX

File Setup Analyze Optimize Tolerance Libraries Part Designer Programming Help

System Explorer Project Preferences Scale Lens

System

Sequential UI Mode Non-Sequential UI Mode

Lens Data Non-Sequential

Editors

Cross-Section Shaded Model

System Viewers

System Check

Diagnostics

Performance Network Server

Bring To Front Window Options Dock New Windows

Window Control

Make Thermal Make Conjugate

Configuration

Multiple Configuration Editor Next Configuration Previous Configuration

Zemax OpticStudio 14.2 Professional - 36156 - Microscopic lens 40x0.65 Kidger modified.ZMX

File Setup Analyze Optimize Tolerance Libraries Part Designer Programming Help

Cross-Section Shaded Model

System Viewers

Rays & Spots Aberrations Wavefront PSF MTF RMS Enclosed Energy Extended Scene Analysis

Image Quality

Physical Optics Beam File Viewer Gaussian Beams Fiber Coupling

Laser and Fibers

Polarization Surface Coatings

Polarization and Surface Physics

Reports

New Universal Plot 1D New Universal Plot 2D

Universal Plot

Stray Light Biocular Systems PAL/Freeform NSC Raytracing

Applications

Zemax OpticStudio 14.2 Professional - 36156 - Microscopic lens 40x0.65 Kidger

File Setup Analyze Optimize Tolerance Libraries Part Designer Programming Help

Quick Focus Quick Adjust Slider Visual Optimizer

Manual Adjustment

Merit Function Editor Optimization Wizard Optimize!

Automatic Optimization

Remove All Variables Set All Radii Variable Set All Thickness Variable

Global Search Hammer Current Glass Substitution Template

Global Optimizers

Find Best Asphere Convert Asphere Types Stock Lens Matching Test Plate Fitting Test Plate Lists

Optimization Tools

Zemax OpticStudio 14.2 Professional - 36156 - Microscopic lens 40x0.65 Kidger

File Setup Analyze Optimize Tolerance Libraries Part Designer Programming

Tolerance Data Editor Tolerance Wizard Tolerancing New Tolerance Script Tolerance Summary

Tolerancing

ISO Element Drawing Zemax Element Drawing Sag Table

Manufacturing Drawings and Data

Zemax OpticStudio 14.2 Professional - 36156 - Microscopic lens 40x0.65 Kidger mod

File Setup Analyze Optimize Tolerance Libraries Part Designer Programming Help

Macro List Edit/Run Refresh List New Macro Macro Help

ZPL Macros

Extension List Command Line Interface Refresh List Extensions Help

Extensions

Zemax OpticStudio 14.2 Professional - 36156 - Microscopic lens 40x0.65 Kidger mod

File Setup Analyze Optimize Tolerance Libraries Part Designer Programming Help

Materials Catalog Materials Analyses Materials Tools Glass Substitution Template

Optical Materials

Lens Catalog Make Private Catalog Test Plate Lists

Stock Parts

Coating Catalog Coatings Tools

Coatings




IS Scatter Catalog ABg Scatter Catalog Scatter Function Viewer Scatter Polar Plot

Scattering

Radiant Source Models IES Source Models Spectral Source Models

Sources

- The settings can be customized in the preferences
- All the settings can be saved
- Important:
 - data file folders
 - graphics parameters
 - editor cell size and Text font
 - preferred fast button functions
 - colors
 - language (don't use German !)





▪ Helpful shortcuts:

1. F3 undo
2. F2 edit a cell in the editor
3. cntr A multiconfiguration toggle
4. cntr Z variable toggle
5. F6 merit function editor
6. cntr U update
7. shift cntr Q quick focus

▪ Window options:

1. several export options:
2. fixed aspect ratios
3. clone
4. adding comments or graphics

save clipboard - save as BMP/JPEG/PNG






Description of optical systems



- Interface surfaces
 - mathematical modelled surfaces
 - planes, spheres, aspheres, conics, free shaped surfaces,...
- Size of components
 - thickness and distances along the axis
 - transversal size, circular diameter, complicated contours
- Geometry of the setup
 - special case: rotational symmetry
 - general case: 3D, tilt angles, offsets and decentrations, needs vectorial approach
- Materials
 - refractive indices for all used wavelengths
 - other properties: absorption, birefringence, nonlinear coefficients, index gradients,...
- Special surfaces
 - gratings, diffractive elements
 - arrays, scattering surfaces

- Auxiliary menus:


1. Tilt/Decenter element



2. Scale lens




- General input of tilt and decenter:
Coordinate break surface
- Change of coordinate system with lateral translation and 3 rotations angles
- Direct listing in lens editor
- Not shown in layout drawing



Lens Data														
Configuration 1/1														
	Surf.Type	Comment	Radius	Thickness	Material	Coating	Semi-Diameter	Conic	TCE x 1E-6	Par 1 (unused)	Par 2 (unused)	Par 3 (unused)	Par 4 (unused)	Par 5 (unused)
0	OBJECT	Standard	Infinity	Infinity			0,00000	0,00000	0,00000					
1		Standard	Infinity	30,00000			10,00000	0,00000	0,00000					
2		Coordinate Break		0,00000	-		0,00000		-	0,00000	0,00000	-45,00000	0,00000	0,00000
3	(aper)	Standard	-282,00000	0,00000	MIRROR		18,00000	U 0,00000	0,00000					
4		Coordinate Break		-200,00000	-		0,00000		-	0,00000	0,00000	-45,00000	P 0,00000	0,00000
5		Coordinate Break		0,00000	-		0,00000		-	0,00000	0,00000	45,00000	0,00000	0,00000
6	(aper)	Standard	282,00000	0,00000	MIRROR		18,00000	U 0,00000	0,00000					
7		Coordinate Break		30,00000	-		0,00000		-	0,00000	-25,00000	45,00000	P 0,00000	0,00000
8	(aper)	Standard	205,00000	15,00000	BK7		50,00000	U 0,00000	-					
9	STOP (aper)	Standard	-205,00000	P 97,56052			50,00000	U 0,00000	0,00000					
10	IMAGE	Standard	Infinity	-			14,14302	0,00000	0,00000					

- Local tilt and decenter of a surface
 - no direct visibility in lens editor
only + near surface index
 - input in surface properties
 - with effect on following system surfaces



System data tables



4: Prescription Data

Settings [Icons] 3 x 4 Standard [Icon]

System/Prescription Data

File : C:\Gross\Zemax\Misc\Microscopic lens 40x0.65 Kidger modified.ZMX
Title: Lens has no title.
Date : 20.03.2015

LENS NOTES:

Notes...

GENERAL LENS DATA:

Surfaces : 18
Stop : 11
System Aperture : Entrance Pupil Diameter = 5,85
Fast Semi-Diameters : On
Field Unpolarized : On
Convert thin film phase to ray equivalent : On
J/E Conversion Method : X Axis Reference
Glass Catalogs : SCHOTT
Ray Aiming : Off
Apodization : Uniform, factor = 0,00000E+000
Reference OPD : Exit Pupil
Paraxial Rays Setting : Ignore Coordinate Breaks
Method to Compute F/# : Tracing Rays
Print Coordinate Breaks : On
Multi-Threading : On
OPD Modulo 2 Pi : Off
Temperature (C) : 2,00000E+001
Pressure (ATM) : 1,00000E+000
Adjust Index Data To Environment : Off
Effective Focal Length : 4,499996 (in air at system temperature and pressure)
Effective Focal Length : 4,499996 (in image space)
Back Focal Length : 3,804983
Total Track : 33,00199
Image Space F/# : 0,7692301
Paraxial Working F/# : 0,7692301
Working F/# : 0,7695343
Image Space NA : 0,5449887
Object Space NA : 2,925e-010
Stop Radius : 4,320451
Paraxial Image Height : 0,2358348
Paraxial Magnification : 0
Entrance Pupil Diameter : 5,85
Entrance Pupil Position : 19,19687
Exit Pupil Diameter : 11,07531
Exit Pupil Position : -8,520728
Field Type : Angle in degrees
Maximum Radial Field : 3
Primary Wavelength [um] : 0,546074
Angular Magnification : 0,5282022
Lens Units : Millimeters
Source Units : Watts
Analysis Units : Watts/cm^2
Afocal Mode Units : milliradians
MTF Units : cycles/millimeter
Include Calculated Data in Session File : On

Menu:
reports / prescription data

4: Prescription Data

Settings [Icons] 3 x 4 Standard [Icon]

<input checked="" type="checkbox"/> General Data	<input type="checkbox"/> Global Vertex
<input checked="" type="checkbox"/> Surface Data	<input type="checkbox"/> COC Point
<input checked="" type="checkbox"/> Surface Detail	<input type="checkbox"/> Element Volume
<input type="checkbox"/> Edge Thickness	<input type="checkbox"/> F/ Numbers
<input type="checkbox"/> Multi-Config Data	<input type="checkbox"/> Cardinal Points
<input type="checkbox"/> Solves/Variables	<input type="checkbox"/> POP Settings
<input checked="" type="checkbox"/> Index/TCE Data	<input type="checkbox"/> Files Used

Clear All Set All

☒ Auto Apply Apply OK Cancel Save Load Reset



System data tables

SURFACE DATA SUMMARY:

Surf	Type	Radius	Thickness	Glass	Diameter	Conic
OBJ	STANDARD	Infinity	Infinity		0	0
1	STANDARD	Infinity	5		7,86213	0
2	STANDARD	17,35664	2,60396	FK51	6,8	0
3	STANDARD	-21,74533	0,2		6,44	0
4	STANDARD	5,97609	2,63782	LLF1	6	0
5	STANDARD	3,06343	1,83096		4,2	0
6	STANDARD	-3,01507	3,90374	SF5	4,2	0
7	STANDARD	18,74531	2,93552	FK51	7,4	0
8	STANDARD	-5,87789	0,2		8,2	0
9	STANDARD	59,18729	0,7	KZFSN4	8,86	0
10	STANDARD	8,38842	2,52456	FK54	9,2	0
STO	STANDARD	-17,32874	0,2		9,4	0
12	STANDARD	12,83435	1,95758	FK54	9,86	0
13	STANDARD	-30,45877	0,2		9,82	0
14	STANDARD	10,76567	1,95157	FK51	9,42	0
15	STANDARD	-26,59881	0,2		9,2	0
16	STANDARD	4,31068	2,15003	SK11	6,94	0
17	STANDARD	6,00286	3,806254		5,46	0
IMA	STANDARD	Infinity			0,4751514	0

INDEX OF REFRACTION DATA:

System Temperature: 20,0000 Celsius
 System Pressure : 1,0000 Atmospheres
 Absolute air index: 1,000273 at wavelength 0,546074 μm
 Index data is relative to air at the system temperature and pressure.
 Wavelengths are measured in air at the system temperature and pressure.

Surf	Glass	Temp	Pres	0,479991	0,546074	0,643847
0		20,00	1,00	1,000000000	1,000000000	1,000000000
1		20,00	1,00	1,000000000	1,000000000	1,000000000
2	FK51	20,00	1,00	1,49088232	1,48793656	1,48507869
3		20,00	1,00	1,000000000	1,000000000	1,000000000
4	LLF1	20,00	1,00	1,55724847	1,55098671	1,54513009
5		20,00	1,00	1,000000000	1,000000000	1,000000000
6	SF5	20,00	1,00	1,68875714	1,67763914	1,66756173
7	FK51	20,00	1,00	1,49088232	1,48793656	1,48507869
8		20,00	1,00	1,000000000	1,000000000	1,000000000
9	KZFSN4	20,00	1,00	1,62389433	1,61669235	1,60990058
10	FK54	20,00	1,00	1,44060795	1,43815076	1,43575617
11		20,00	1,00	1,000000000	1,000000000	1,000000000
12	FK54	20,00	1,00	1,44060795	1,43815076	1,43575617
13		20,00	1,00	1,000000000	1,000000000	1,000000000
14	FK51	20,00	1,00	1,49088232	1,48793656	1,48507869
15		20,00	1,00	1,000000000	1,000000000	1,000000000
16	SK11	20,00	1,00	1,57081059	1,56605180	1,56146150
17		20,00	1,00	1,000000000	1,000000000	1,000000000
18		20,00	1,00	1,000000000	1,000000000	1,000000000

lead containing glass type

lead containing glass type

was replaced by N-KZFS4



Important Surface Types

- | | |
|-----------------------|---|
| ▪ Standard | spherical and conic sections |
| ▪ Even asphere | classical asphere |
| ▪ Paraxial | ideal lens |
| ▪ Paraxial XY | ideal toric lens |
| ▪ Coordinate break | change of coordinate system |
| ▪ Diffraction grating | line grating |
| ▪ Gradient 1 | gradient medium |
| ▪ Toroidal | cylindrical lens |
| ▪ Zernike Fringe sag | surface as superposition of Zernike functions |
| ▪ Extended polynomial | generalized asphere |
| ▪ Black Box Lens | hidden system, from vendors |
| ▪ ABCD | paraxial segment |

Selection of Wavelengths




- Setting of wavelengths:
 - maximum of 24 values
 - weighting factors allow for spectral modelling
 - unit is always μm
 - selection of primary wavelength: paraxial data are based on it

The screenshot shows the 'System Explorer' dialog box with the following settings:



- System Explorer** (title bar)
- Wavelengths** (expanded)
 - Settings** (expanded)
 - Preset:** **F, d, C (Visible)** (dropdown menu)
 - Select Preset** (button)
 - Wavelength 1** (0,4799914 μm , Weight = 1,0)
 - ☒ **Enable**
 - ☐ **Primary**
 - Wavelength (μm):** 0,4799914
 - Weight:** 1,0
 - Wavelength 2** (0,546074 μm , Weight = 1,0)
 - Wavelength 3** (0,6438469 μm , Weight = 1,0)
 - Add Wavelength**
 - ☐ **Enable**
 - ☐ **Primary**
 - Wavelength (μm):** 0,55
 - Weight:** 1,0

Useful commands for system changes:

1. Make double pass
2. Scale to focal length
3. Reverse element
4. Add / delete folding mirror
5. Tilt/decenter elements
(see next page)



2. Insert system with other system file



Screenshot of the Lens Data toolbar. The 'Import' button is highlighted in blue. The 'Surface 0 Properties' panel is visible below the toolbar, showing a list of properties: Type, Draw, Aperture, Scattering, Tilt/Decenter, Physical Optics, Coating, and Import. The 'Import Data File' dropdown menu is set to 'None'.

	Surf	Type	Comment	Radius	Thick
0	OBJECT	Standard		Infinity	Infin
1		Standard		Infinity	5,00
2	(aper)	Standard		17,35664	V 2,60
3	(aper)	Standard		21,34500	V 2,60